



Mark edges of checkerboard on desired surface.
Use router to cut 1/8" depression for 1 inch wooden tiles.
Glue prepared tiles into place.