



Tape printable over desired area.

Use exacto blade to cut out template and score wood.

Pencil in outer lines and remove printable.

Use dremel or rotating tool to create 1/4" depressions in wood.

Sand smooth and seal.